

Linking busbar installation instructions

FCI Nantong
November 04 2014

Linking Busbar Packing Photo



Description 1: Accessory Screw type species



Screw type species

FCI PN	Description	QTY	Torque(N.m)
10128001-001	tapping screw M3*10	2	0.5
10128001-003	M6*14	3	4.4
10128001-005	M6*16	8	4.4
10026559-0011	M6 flat washer	8	NA
10026559-0015	M6 spring washer	8	NA


Description 2:tapping screw M3*10



FCI PN	Description	QTY	Torque(N.m)
10128001-001	tapping screw M3*10	2	0.5



installation site




Description 3:M6*14 Ultra short head screw



FCI PN	Description	QTY	Torque(N.m)
10128001-003	M6*14	3	4.4



installation site




Description 4:M6*16 、flat washer 、 spring washer



FCI PN	Description	QTY	Torque(N.m)
10128001-005	M6*16	8	4.4
10026559-0011	M6 flat washer	8	NA
10026559-0015	M6 spring washer	8	NA




installation site



Installation instruction 1:



M6*16 、 flat washer 、 spring washer



Tapping screw M3*10

Installation instruction 2:



M6*14 :Ultra short head screw

